

DIGITAL SIGN DISPLAY

INSTALL INSTRUCTIONS

Use TV remote for the following:

1. PLUG IN Sign Stick (shipped separately) into the HDMI 1 slot on the back of the Screen.
2. Open TV and Wall Mount and hang on desired wall area.
3. Turn Screen “ON” using (Screen Remote).
4. PAIR your remote by connecting to your WIFI.
5. Sign into our Amazon Account:

First name: Discount Last Name: Banners

Ph# 817-791-2184


Password: Aptscreens1!

6. BYPASS & SKIP all options , then click on “DONE” (located in bottom right corner)
7. Click on Discount Banners PROFILE. 
8. Click on INPUTS and select HDMI 1


Use SIGN STICK remote for the following:

Now we will connect the Sign Stick  remote to your WIFI:

1. Click on SETTINGS button.



2. Click on NETWORK & INTERNET.
3. LOGIN to your Wifi.
4. Click on CONNECT (located in bottom right corner).. 
5. Then click on HOME SCREEN once connected to Wifi.



6. You will see an orange and white screen...in white bar SELECT your PROPERTY NAME.
7. Click "GO".

Let the Slides Begin!!

Please contact us for trouble-shooting or remote set-up questions:

email: Laura@discountbannersandsigns.com or call 817-791-2184.